

Ficha Técnica de Producto

DEKA-1

Alkaline stripper for polished floors



DESCRIPTION

Alkaline stripper for polished floors.
It prepares the surfaces for later vitrify treatment.
It eliminates rests of waxes and acrylic autobrillant emulsions of previous applications

FORM OF USE

Apply diluted in water in a proportion of the 5 to 10% depending of the dirt, of the incrustations and of the quality of the floor.
Treat small areas with wash or rotary machine (brown or black disk).
Clean quickly with water to avoid the prolonged contact of the product with the surface and for the complete elimination of the stripper.

TECHNICAL CHARACTERISTICS TECHNIQUES

Aspect: Liquid.
Color: Blue.
Smell: Characteristic
pH: 13-14
Density: 1,08-1,09 g/cc
Active substance concentration: 15-20%

COMPOSITION

Anionic tensioactives, sequestratings and color.

PRESENTATION

Plastic containers.

FORMAT	5 kg
CODE	004DEK05

SECURITY / TOXICOLOGY

Causes severe burns.
Keep out of the reach of the children.

ADDITIONAL INFORMATION

INDUSTRIAL PRODUCT. PROFESSIONAL USE.

Commercial information. For the handle and employment of product, follow the indications of the label and the MSDS.
To resolve any doubt, can contact with our Technical Department.
The valid version of this document is available only in the web www.dermo.com.