

Ficha Técnica de Producto

LIMCAL Descaler



DESCRIPTION

Powerful removal of incrustations for either hot or cold water circuits of dishwashers, washing machines... Removes limescale and oxide incrustations. Effective for use in final cleaning of building works and swimming pools (cement residues, environmental dirt, salt, limescale and rust stains) and cleans the joints of the tiles.

FORM OF USE

Dishwashers: Do an empty wash cycledosing from 5% to 10%. Repeat the process every 15 days for optimum machine maintenance.

Dishes recovery: Dilute the product from 3 to 5% in a bowl of water. Immerse dishes from 5 to 10 minutes. Rinse with water.

Cleaning of building works: Check that the material is resistant to acids (stoneware, ceramic, tile, granite, slate). Dilute between 40 and 60% in water. Apply and rub the surface with a brush. Rinse with water to neutral pH. Do not use on marble or limestone.

Building Equipment: To remove residues of cement from mixers, wheelbarrows ... use diluted from 20 to 50%.

Joints of the tiles: Dilute 30 to 40% water. Apply on the joints and immediately rub with a brush or sponge. After application neutralize with water.

TECHNICAL CHARACTERISTICS

Aspect: Opaque liquid.

Colour: White.

Smell: Beer almond.

pH pure: <1

Density: 1,055 – 1,065 g/cc

Solubility: Water soluble.

Active substance concentration: 17 – 20 %

COMPOSITION

Inorganic acids, fragrance.

PRESENTATION

Plastic containers:

FORMAT	1 kg	5 kg	10 kg
CODE	003LIM01	003LIM05	003LIM10

Ficha Técnica de Producto

LIMCAL

Descaler



SECURITY/TOXICOLOGY

Harmful if swallowed. Causes skin irritation. Causes serious eye irritation. May cause respiratory irritation. Wear protective gloves/protective clothing/eye protection/face protection. Avoid extreme temperatures and direct sunlight exposure.

ADDITIONAL INFORMATION

INDUSTRIAL PRODUCT. PROFESSIONAL USE.

Commercial information. For the handle and use of product, follow the indications of the label and the MSDS. To resolve any doubt, contact with our Technical Department: tecnico@dermo.com. The valid version of this document is available only in the web www.dermo.com.