

# DEKA-1

## Alkaline stripper for polished floors



### DESCRIPTION

Alkaline stripper for polished floors. Wax coating remover. Prepare surfaces for later vitrification treatment. Eliminates the remains of wax and acrylic autobrillant emulsions from previous applications.

### FORM OF USE

**MACHINE USE:** Dilute 5-10% of the product in water. Treat small areas with a scrubber or rotary machine (brown or black disk). Collect the dirty solution with a water pump. Rinse well with water to avoid the prolonged contact of the product with the surface and for the complete elimination of wax traces. Leave to dry.  
**MANUAL USE:** Dilute 10-20% of the product in water.

### TECHNICAL CHARACTERISTICS TECHNIQUES

Aspect: Liquid.  
Color: Without color.  
Smell: Characteristic  
pH: 13-14  
Density: 1,08-1,09 g/cc  
Active substance concentration: 15-20%

### COMPOSITION

Phosphonates.

### PRESENTATION

Plastic containers.

FORMAT	5 kg
CODE	004DEK05

### SECURITY / TOXICOLOGY

Causes severe skin burns and eye damage.  
Wear protective gloves/protective clothing/eye protection.

### ADDITIONAL INFORMATION

INDUSTRIAL PRODUCT. PROFESSIONAL USE.

*Commercial information. For the handle and employment of product, follow the indications of the label and the MSDS. To resolve any doubt, can contact with our Technical Department: [tecnico@dermo.com](mailto:tecnico@dermo.com). The valid version of this document is available only in the web [www.dermo.com](http://www.dermo.com).*

Revisión nº: 003    Data: 14/09/21