

DEKA-1

Alkaline stripper for polished floors



DESCRIPTION

Alkaline stripper for polished floors. Wax coating remover. Prepare surfaces for later vitrification treatment. Eliminates the remains of wax and acrylic autobrillant emulsions from previous applications.

FORM OF USE

MACHINE USE: Dilute 5-10% of the product in water. Treat small areas with a scrubber or rotary machine (brown or black disk). Collect the dirty solution with a water pump. Rinse well with water to avoid the prolonged contact of the product with the surface and for the complete elimination of wax traces. Leave to dry.
MANUAL USE: Dilute 10-20% of the product in water.

TECHNICAL CHARACTERISTICS TECHNIQUES

Aspect: Liquid.
Color: Without color.
Smell: Characteristic
pH: 13-14
Density: 1,08-1,09 g/cc
Active substance concentration: 15-20%

COMPOSITION

Phosphonates.

PRESENTATION

Plastic containers.

FORMAT	5 kg
CODE	004DEK05

SECURITY / TOXICOLOGY

Causes severe skin burns and eye damage.
Wear protective gloves/protective clothing/eye protection.

ADDITIONAL INFORMATION

INDUSTRIAL PRODUCT. PROFESSIONAL USE.

Commercial information. For the handle and employment of product, follow the indications of the label and the MSDS. To resolve any doubt, can contact with our Technical Department: tecnico@dermo.com. The valid version of this document is available only in the web www.dermo.com.

Revisión nº: 004 Data: 15/05/25